

Quenching Tip

Use a good-sized container for your quench water. A bunch of hot cases, even little ones, can heat up a bucketful of tap water faster than you might think it could. If you plan to load them soon, dry them thoroughly with a jet of compressed air. Make sure no droplet of moisture remains in the primer vent. The absence of a primer is obviously an asset here, too.